

## Installation Steps for BL-818



Step1: insert mortise to door



Step2: install front panel, connect with mortise



Step3: install square shaft to mortise



Step4, install fix steel plate with front panel



This is screw position



Step5: connect back panel with fix steel plate